

Technical Description

MEW01294

Revision 2

External Fire Brigade Panels 1826 & 1828, ver. 1.4.x

Author: Jan Pettersson	Date of issue: 2010-03-31	Date of rev: 2011-08-15
------------------------	---------------------------	-------------------------

This page has deliberately been left blank.

Table of contents

1	Introduction	3
2	Definitions / Explanations	4
3	General description	5
3.1	Ext. FBP 1826	5
3.1.1	SW mode 1826/28 - 1587	5
3.1.2	SW mode 1826/28 - 1582	6
3.1.3	Printer 1835	6
3.2	Ext. FBP 1828	6
3.2.1	SW mode 1826/28 - 1587	7
3.2.2	SW mode 1826/28 - 1582	7
4	Selective alarm presentation	8
4.1	Ext. FBPs 1826 & 1828	8
5	LED indicators, Push buttons, etc.	10
5.1	Ext. FBP 1826 & 1828 front	10
5.1.1	Neutral front	14
6	SW mode & Address setting	15
6.1	SW mode setting	15
6.1.1	SW mode setting via jumper "J4"	16
6.2	Address setting	16
6.2.1	Address setting mode via the c.i.e.	17
6.3	Flow chart	17
7	User definable text messages (alarm texts)	19
8	Commissioning a new unit / SSD download	20
9	Restart	22
10	Fault messages	24
10.1	Fault messages in the ext. FBP	24
10.2	Fault messages in the c.i.e.	24
10.2.1	System EBL512	24
10.2.2	System EBL128	25
10.2.3	System EBL512 G3	25
11	Software (SW)	26
11.1	SW version	26
11.2	SW download	27
12	Operation	28
13	Connections	30
14	Technical data	32
14.1	Power supply	32
14.2	RS485	32
14.2.1	Cable	32

14.3	RS232 _____	32
14.4	Connection _____	32
14.5	Current consumption_____	33
15	Revision history_____	34

1 Introduction

This document¹ describes the External Fire Brigade Panels **1826 & 1828**. Also the shorter expression **Ext. FBP** will be used in this document.

It also describes **1835**, Printer for Ext. FBP 1826.

The **1826 units** can run in one of two SW modes:

SW mode **1826 – 1587 2nd Cab**

or

SW mode **1826 – 1582 2nd Cab**

The **1828 units** can run in one of two SW modes:

SW mode **1826/28 - 1587**

or

SW mode **1826/28 – 1582**

For more information see chapter "General description", page 5.

This document is valid for the 1826/28 software **version 1.4.x**, which require a software version $\geq 2.3.2$ in EBL512 and a software version $\geq 1.0.5$ in EBL128 only if the functions described below are to be used.

The 1826/28 software version 1.4.x can be used in the systems EBL512 and EBL128 with lower versions but then without the possibility to use these functions.

Functions²:

- Fault(s) in the system (not corrected / serviced and not acknowledged) will be presented as "General fault in system".
- The buzzer will sound (continuously) for any not acknowledged fault in the system or a fault in the unit.
- Push button "Silence buzzer" will silence the buzzer.

System EBL512 G3

The 1826/28 software version 1.4.x has to be used in the system EBL512 G3. Only SW mode "1587" can be used.

¹ Original file name: L:\User documents\EBL\Doc\Eng\MEW01294 (Rev 2).doc

² Not valid for the Swedish convention (SBF).

2 **Definitions / Explanations**

Definitions / explanations / abbreviations / etc. frequently used or not explained elsewhere in the document.

Ext. FBP External Fire Brigade Panel

C.i.e. Control and indicating equipment (=control unit)

C.U. Control unit (=Control and indicating equipment)

SW Software

HW Hardware

3 General description

The ext. FBP is intended to be used by the fire brigade personnel to get fire alarm information³, reset fire alarms, silence alarm devices and the built-in buzzer. See also chapter "Operation", page 28.

3.1 Ext. FBP 1826



Figure 1. The external Fire Brigade Panel 1826.

The ext. FBP consists of a grey metal cabinet with a door. The door has a Plexiglas ahead of the FBP front and has to be unlocked / opened, with a special (Swedish) fire brigade key, to get access to the push buttons. There is a door switch that can be used to indicate in the c.i.e. when the door in the ext. FBP is open and disable the outputs for routing equipment (Fire brigade and fault tx). This is programmable, see Planning Instructions for the system respectively.

The cabinet has cable inlets on the top, bottom and back sides and is intended to be surface mounted in dry premises. Two compression glands TET 10-14 (IP67) are attached.

3.1.1 SW mode 1826 – 1587 2nd Cab

This SW mode has the highest performance with regard to functionality, response time, ability to store fire alarms, etc.

The ext. FBP 1826 running in SW mode **1826 - 1587 2nd Cab** is intended to succeed the ext. FBP 2426 (1826+printer 1835 will succeed the ext. FBP 2425) but not as a spare part. Note, the look, dimensions, etc. are not the same.

³ Also pre-warning, co-incidence (2-zone / address dependence) and heavy smoke / heat alarm.

In system EBL512, 1826 units running in SW mode **1826– 1587 2nd Cab** have to be connected to an **Ext. FBP / DU interface board 1587** mounted in the EBL512 c.i.e. EBL512 software version ≥ 2.2 is required.

In system EBL128, 1826 units running in SW mode **1826 – 1587 2nd Cab** are connected directly to the main board connector "J1" but an optional **RS485 transceiver component 4552** has to be plugged on the main board.

In system EBL512 G3, 1826 units running in SW mode **1826 – 1587 2nd Cab** are connected directly to the main board connector "J4".

3.1.2 SW mode 1826 – 1582 2nd Cab

The ext. FBP 1826 running in SW mode **1826 - 1582 2nd Cab** has the same functionality as the ext. FBP 2426 and can be used as a spare part (1826+printer 1835 is a spare part for the ext. FBP 2425). Note, the performance is the same but the look, dimensions, etc. are not the same.⁴

In system EBL512, 1826 units running in SW mode **1826 - 1582 2nd Cab** have to be connected to an **Ext. FBP interface board 1582** mounted in the EBL512 c.i.e.

In systems EBL128 and EBL512 G3, 1826 units running in SW mode **1826 - 1582 2nd Cab** can **NOT** be connected.

3.1.3 Printer 1835

The Printer 1835 can be mounted in the unit ext. FBP 1826. It will print all the alarms, including the user definable text messages.

NOTE! This is only valid if and when the door is being opened. If the door is not opened until after all the alarms are reset, there will be no printing.

3.2 Ext. FBP 1828



Figure 2. The external Fire Brigade Panel 1828.

⁴ **NOTE!** The alarm presentation will be like in the c.i.e. that ext. FBP is connected to, not as in 2425 / 2426. The 1826 / 1828 front does not hold any LED "Zone/Detector not reset", i.e. an encapsulated alarm point/zone will only be indicated in the c.i.e. (see EBL512 Operating Instructions).

The ext. FBP consists of a compact size enclosure made of grey high impact ABS. Fitted with a supplementary "O" ring gasket, it will comply with IP65, in respect of dust and moisture. The unit has no door, i.e. the front is accessed directly, when required. **A key is, however, required to get access to the push buttons and they are disabled until they are supposed to be used.** The unit is intended to be surface mounted and for indoor use in dry premises. Two compression glands TET 7-10 (IP67) for cable inlets are attached.

3.2.1 **SW mode 1826/28 - 1587**

This SW mode has the highest performance with regard to functionality, response time, ability to store fire alarms, etc.

The ext. FBP 1828 running in SW mode **1826/28 – 1587**, is an alternative to the ext. Presentation display 2428, the Display unit 2236 and a compact size alternative to the ext. FBP 2426 but not as a spare part. Note, the look, dimensions, etc. are not the same.

In system EBL512, 1828 units running in SW mode **1826/28 – 1587** have to be connected to an **Ext. FBP / DU interface board 1587** mounted in the EBL512 c.i.e. EBL512 software version ≥ 2.2 is required.

In system EBL128, 1828 units running in SW mode **1826/28 – 1587** are connected directly to the main board connector "J1" but an optional **RS485 transceiver component 4552** has to be plugged on the main board.

In system EBL512 G3, 1828 units running in SW mode **1826/28 – 1587** are connected directly to the main board connector "J4".

3.2.2 **SW mode 1826/28 - 1582**

The ext. FBP 1828 running in SW mode **1826/28 - 1582** is an alternative to the ext. Presentation display 2428, the Display unit 2236 and a compact size spare part to the ext. FBP 2426. Note, the performance is the same but the look, dimensions, etc. are not the same.⁴

In system EBL512, 1828 units running in SW mode **1826/28 – 1582** have to be connected to an **Ext. FBP interface board 1582** mounted in the EBL512 c.i.e.

In systems EBL128 and EBL512 G3, 1828 units running in SW mode **1826/28 – 1582** can **NOT** be connected.

4 Selective alarm presentation

Normally all fire alarms will be presented in the c.i.e.s, ext. FBP:s and Presentation units, etc. There are some possibilities to select which alarms that shall be presented in each unit. It is also programmable, if the fire alarm presentation shall be according to EN54, i.e. when only one point in a zone is in alarm status it will be presented as a point alarm (zone and address), else presented as a zone alarm.

4.1 Ext. FBPs 1826 & 1828

The alarm presentation in an ext. FBP will be like in the c.i.e. that the ext. FBP is connected to, i.e. point alarm or zone alarm presentation. See Operating Instructions, chapter "Fire alarm" for the system respectively.

Via Win512/Win128/Win512 G3, it is possible to select which alarms that shall be presented in the ext. FBP respectively. For example, if there are many buildings in an installation, the ext. FBP in one specific building shall only present alarms activated within this building.

The following, so called operands are available (CU alternatives not valid for EBL128):

1. Control unit (**CU**)
2. Consecutive control units (**CU1, CU2**)
3. Zone (**zone**)
4. Consecutive zones (**zone1, zone2**)
5. Zone – address (**zone, addr**)
6. Consecutive zone – addresses (**zone1, addr1, zone2, addr2**)

Explanations / example:

1. **CU** = Control unit number (c.i.e. no. 00-29)
2. **CU1** = The first control unit number in the sequence. **CU2** = The last control unit number in the sequence.
3. **zone** = Zone number (001-999) In EBL128 (01-32).
4. **zone1** = The first zone number in the sequence. **zone2** = The last zone number in the sequence.
5. **zone, addr** = Zone number and address within the zone (001, 01 – 999, 99)
6. **zone1, addr1** = The first zone number and address in the sequence. **zone2, addr2** = The last zone number and address in the sequence.

Up to 50 operands can be used to make a, so called selector for an ext. FBP. Here follows a selector example:

Control unit (00), Consecutive zones (100, 500), Zone – address (900, 01) In this ext. FBP will only be presented alarms that origin from the c.i.e. no. 00 or from zone 100 up to and including zone 500 or from the alarm point 900-01.

Default for each ext. FBP is, in systems EBL512 and EBL512 G3: **Control units (00, 29)**, i.e. all alarms from all c.i.e:s will be presented in all ext. FBP:s.

Default for each ext. FBP is, in system EBL128: **Zones (01 - 32)**, i.e. all alarms will be presented in all ext. FBP:s.

5 LED indicators, Push buttons, etc.

The functions of the LEDs, push buttons, display and buzzer are described below.

5.1 Ext. FBP 1826 & 1828 front




Figure 3. The external Fire Brigade Panel 1826 front. The designation texts are here in Swedish. The 1828 front looks the same, except the push button "P5" that is replaced with a keyhole. See also tables below.

The following is valid in quiescent (normal) condition:

- The LED "L6" (Drift = *Operation*) is turned on if 24 V DC is connected and the communication with the c.i.e. is working normally, else it is turned off.
- Buzzer is silent.
- No text in the display and no back-light.
- No button is possible to use, except "P5" (*Paper feed*).

Table of LED indicators:


LED indicator		Colour	Indicating	
L1	Fire (Brand)	2 x Red	Blinking+ Buzzer (interm.)	Fire alarm. (Also indicating heavy smoke / heat alarm the same way as in the c.i.e.)
L2	Alarms queued (Flera larm)	2 x Red	Blinking	More than one alarm (also pre-warning and co-incident alarms ⁵ . Use push button "Alarms queued" (P1) to scroll.
L3	Extinguishing (Släckanläggning aktiverad)	Red	Cont.	Outputs for Extinguishing equipment are activated. ⁶
L4	Ventilation (Brandventilation aktiverad)	Yellow	Cont.	Outputs for (fire / smoke) ventilation equipment are activated. ⁶
L5	Fire brigade tx (Larmsändare aktiverad)	Red	Cont.	Output(s) for fire brigade tx (routing equipment is/are activated. ⁶
L6	Operation (Drift)	Green	Cont.	24 V DC is connected and the communication with the c.i.e. is working normally, i.e. the ext. FBP is in operation.

NOTE! Regarding "L2", see also chapter "SW mode & Address setting, page 15.

⁵ Co-incident alarm = 2-zone / -address dependence.

⁶ Indicating the same way, as in the c.i.e. the ext. FBP is connected to, i.e. by activated output(s) of the corresponding type or an activated input for the LED respectively.

Table of push buttons:

Push button		Colour	Operation / function
P1	Alarms queued (Flera larm)	Black	Used, when LED "Alarms queued" (L2) is turned on, to scroll through the queued alarms. (The first alarm will automatically be shown again after 20 seconds, if no button is used during that time.)
P2	Silence buzzer (Summer tyst)	Yellow	Used to silence the buzzer in the ext. FBP. The buzzer will re-sound for an alarm from another zone. ⁷
P3	Silence alarm devices (Larmdon tyst) ⁸	Red	Used to silence the alarm devices (sounders) ⁹ in the installation. The alarm devices will re-sound for an alarm from another zone ¹⁰ or if "P3" is pressed again. ¹¹
P4	Reset (Återställning) ⁸	Green	Used to reset the fire alarm(s). ¹²
P5	 ¹³	White	Used for <i>Paper feed</i> (pappersframmatning) when a built-in printer 1835 is available. ¹⁴

NOTE! Regarding "P1" and "P2", see chapter "SW mode & Address setting, page 15 and regarding "P3", chapter "SW version", page 26.

In the Ext. FBP 1828, "P5" is replaced with a keyhole. **A key is required to get access to the push buttons** and they are disabled until they are supposed to be used.

⁷ When point alarm presentation is valid (set via WinXXX), the buzzer will re-sound for an alarm from another alarm point.

⁸ Press simultaneously "P3" (Silence alarm devices) & "P4" (Reset) for a test of the LEDs, the buzzer and the display (back light and dots). **NOTE!** This must only be done in quiescent condition.

⁹ I.e. the outputs for type 3 = alarm devices will be de-activated.

¹⁰ When point alarm presentation is valid (set via WinXXX), the alarm devices will re-sound for an alarm from another alarm point.

¹¹ **If the "Silence alarm devices" button in the c.i.e. has been programmed to "Disable alarm devices", "P3" will have the same function.**

¹² Multiple reset, Single reset or Single encapsulated reset, i.e. the same way as in the c.i.e. the ext. FBP is connected to.

¹³ There is no symbol in push button "P5" in the 1826 neutral front. The push button "P5" is replaced with a keyhole in the 1828 neutral front.

¹⁴ A printer 1835 can be mounted in 1826 but not in 1828.

Table of others:

Component	Indicating	
Buzzer ¹⁵	Intermittent	Fire alarm, pre-warning and co-incidence ⁵ , like in the c.i.e.
	Continuously ²	Not acknowledged fault in the system or a fault in the unit.
	Cont. + All LEDs turned off as well.	There is a CPU / memory fault in the ext. FBP
Display	Pre-warning, co-incidence ⁵ , Fire alarm and Heavy smoke / heat alarm presentation like in the c.i.e. the ext. FBP is connected to including a user definable text message (alarm text), if programmed. Fault(s) in the system (not corrected / serviced and not acknowledged) will be presented as "General fault in system" ² . (NOTE! A fault message may be shown, indicating a communication fault (i.e. no connection between the ext. FBP and the c.i.e. All LEDs are turned off as well.).	
Printer ¹⁶	Fire alarm and Heavy smoke / heat alarm printout like the printer in the c.i.e. the ext. FBP is connected to (including a user definable text message, if programmed).	

NOTE! Regarding the Display, see also chapter "SW mode & Address setting, page 15.

¹⁵ The Buzzer may be programmed as "disabled" (via Win512/Win128/Win512 G3), i.e. it will **never** sound.

¹⁶ A printer 1835 can be mounted in 1826 but not in 1828.

5.1.1 Neutral front

The ext. FBPs 1826 & 1828 are also available with a neutral front, where the designation texts are made separately and put into a transparent "text slot" for the LED and push button respectively.¹⁷

The LEDs and push buttons are described in chapter "Ext. FBP 1826 & 1828 front", page 10.




Figure 4. The external Fire Brigade Panel 1826 neutral front. The 1828 neutral front looks the same except the push button "P5" that is replaced with a keyhole. See also Figure 2, page 6.

¹⁷ This is made by the manufacturer before the front is mounted in the unit respectively.

6 SW mode & Address setting

Each ext. FBP can in system EBL512 run in SW mode "1587" or SW mode "1582", i.e. it can be used as two different types of units. It shall also have a unique **address** on the RS485 line connected to the 1587 or 1582 board in the EBL512 c.i.e. See EBL512 Planning Instructions.

The SW mode "1587" shall be used in system EBL128 and an optional **RS485 transceiver component 4552** is required on the main board in the EBL128 c.i.e. It shall also have a unique **address** on the RS485 line connected to the main board connector "J1". See EBL128 Planning Instructions.

The SW mode "1587" shall be used in system EBL512 G3. It shall also have a unique **address** on the RS485 line connected to the main board connector "J4". See EBL512 G3 Planning Instructions.

6.1 SW mode setting

A brand new ext. FBP has no SW mode. It is factory set to "**Not selected**" (and is hereby not addressable). When it is **powered** it will automatically be ready for the "SW mode setting".

As an alternative, an ext. FBP **in operation**¹⁸ can be ready for the "SW mode setting" via the jumper "J4" in the unit. See the following chapter.

When the ext. FBP is ready for the "SW mode setting" this is indicated by the LED "Alarms queued" (L2). The back-light is turned on and the following information is shown in the display:

MODE SETTING!	Change = Black
Type: XXXXXXXXXXXX	Store = Yellow

XXXXXXXXXXXX can be changed to one of the following:

- 1735 - 1587
- 1736 - 1587
- **1826 - 1587 2nd Cab** (only for 1826 units)
- **1826 - 1582 2nd Cab** (only for 1826 units)
- **1826/28 - 1587** (only for 1828 units)
- **1826/28 - 1582** (only for 1828 units)
- 1728 - 1587
- 1728 - 1582
- **Not selected**

Scroll to the wanted SW mode with the push button "P1" (black). Store the selected SW mode with the push button "P2" (yellow) and the unit will automatically be ready for the "Address setting", see below.

¹⁸ Or when a unit, not in operation but with the mode and address set before, is powered.

NOTE! If the stored SW mode is "1582" also a **language** has to be set before the address can be set. The following information will be shown in the display:

LANGUAGE SETTING!	Change = Black
Language: xxxxxxx	Store = Yellow

xxxxxxx can be changed to one of the following languages:

- **English**
- **Danish**
- **Swedish**

Scroll to the wanted language with the push button "P1" (black). Store the selected language with the push button "P2" (yellow) and the unit will automatically be ready for the "Address setting", see below.

6.1.1 SW mode setting via jumper "J4"

An ext. FBP **in operation**¹⁸ will be ready for the "SW mode setting" via the jumper "J4" in the unit. Activate "J4" momentarily.¹⁹

When the ext. FBP is ready for the "SW mode setting" this is indicated by the LED "Alarms queued" (L2). The back-light is turned on and the following information is shown in the display:

MODE SETTING!	Change = Black
Type: xxxxxxxxxxxxx	Store = Yellow

Continue in accordance with chapter "SW mode setting", page 15.

6.2 Address setting

After the SW mode setting or after the language setting (see above), the ext. FBP is ready for the "address setting".

As an alternative, an ext. FBP **in operation**²⁰ can be ready for the "address setting" directly via a c.i.e. menu. See the following chapter.

When the ext. FBP is ready for the "address setting" this is indicated by the LED "Alarms queued" (L2). The back-light is turned on and the following information is shown in the display:

ADDRESS SETTING	Change = Black
Address: xx	Store = Yellow

xx can be changed to the following:

For an ext. FBP with SW mode "1587", the address can be set to **00-15**.²¹ (Default is "00".)

¹⁹ If "J4" is not removed, the ext. FBP will not enter its normal operation mode after the restart but start from the beginning again, ready for the SW mode setting.

²⁰ Or all the ext. FBPs connected to the same Ext. FBP / DU interface board 1587.

²¹ This is the max. no. of addresses. The max. no. of units connected, is depending on the type of units (printer / no printer) as well as the system. Ext. power supply can be used.

For an ext. FBP with SW mode "**1582**", the address can be set to **01-08**.²¹ (Default is "01".)

Scroll to the wanted address with the push button "P1" (black). Store the selected address with the push button "P2" (yellow) and the unit will automatically restart and enter its normal operation mode.²²


6.2.1 Address setting mode via the c.i.e.

A specific ext. FBP or all the ext. FBPs connected to the same line (RS485) can, in normal operation, from the c.i.e. receive a command and get ready for the "Address setting" directly. This is done via menu H5/A9 (A7 in system EBL512 G3), see the Operating instructions for the system respectively.

6.3 Flow chart

On the following page is a flow chart, showing the SW mode setting, Language setting, Address setting, etc.

²² If the unit has no SW mode, i.e. "Not selected", it will not enter its normal operation mode after the restart but start from the beginning again, ready for the SW mode setting.



7 User definable text messages (alarm texts)

The user definable text messages (alarm texts) are depending on which mode the unit is running in.

In SW mode "1587"

In the c.i.e., each alarm point (zone – address) and each zone can have an individual user definable text message (alarm text)²³ presented in the display by fire alarm, see the Planning and Operating Instructions for the system respectively.

The alarm texts shown in the c.i.e. will also be sent out to each ext. FBP and shown in its display.

As an alternative, alarm texts for all or selected alarm points / zones can be stored in each ext. FBP²⁴. If so, these alarm texts will be shown instead of the alarm texts sent out from the c.i.e.

The priority order is as follows:

1. Point alarm text stored in the ext. FBP.
2. Zone alarm text stored in the ext. FBP.
3. Default alarm text stored in the ext. FBP.
4. Alarm text sent out from the c.i.e.

When alarm texts shall be stored in all or in some ext. FBPs, the unique alarm texts are created in Win512 / Win128 / Win512 G3 and downloaded when the c.i.e. site specific data (SSD) is downloaded.

NOTE! It is also possible to select which fire alarms that shall be presented in the ext. FBP respectively, see chapter "Selective alarm presentation", page 8.

In SW mode "1582"

The user definable text messages (alarm texts)²³ shown in the c.i.e. will also be sent out to each ext. FBP and shown in its display.

²³ Each alarm text (up to 40 alphanumeric characters) will be shown on the second row. The texts are created and downloaded via Win512 / Win128 / Win512 G3.

²⁴ At least 617 text messages can be stored in each unit.

8 Commissioning a new unit / SSD download

The cable (RS485 line) to the ext. FBP(s)²⁵ shall be connected. See connection diagrams for the system respectively.

In the EBL512 c.i.e the 1582 / 1587 board shall be mounted. Remove the fuse "F1" on the 1582 / 1587 board.

The EBL128 c.i.e. shall be powerless and the "RS485 transceiver component" (4552) shall be plugged on the main board (4556).

On the EBL512 G3 main board (5010) remove the fuse "F19".

The SW mode and the address have to be set in each new ext. FBP according to chapter "SW mode & Address setting", page 15. Here follows a brief summary (a recommended sequence of actions):

1. Connect the cable from the c.i.e. to the ext. FBP's terminal block "J1".
2. When all connections are done put back the fuse "F1" on the 1582 / 1587 board in the EBL512 c.i.e. / power up the EBL128 c.i.e. / put back the fuse "F19" on the main board (5010) in the EBL512 G3 c.i.e., i.e. the ext. FBP(s) will now be powered up.
3. A brand new ext. FBP will automatically be ready for the SW mode setting.
4. After SW mode and address setting press "P2" (yellow) and the ext. FBP will restart, see chapter "Restart", page 22.
5. Since the SSD is not downloaded in the c.i.e. there will be a fault message in the ext. FBP's display:

"No contact with Control unit".

All LEDs in the ext. FBP will be turned off.

6. Now the SSD have to be downloaded via Win512 / Win128 / Win512 G3.²⁶ Connect the PC to the c.i.e. In the "Win512 / Win128 / Win512 G3 download SSD" dialog box, verify that the "Download FBP / AAU" checkbox is marked. Start the download of SSD.
7. When the download of SSD to the c.i.e. is finished, it will restart. Then the download of SSD to the ext. FBP(s) will

²⁵ One or more ext. FBPs and/or Alert Annunciation Units can be connected.

²⁶ Via Win512 is the 1582 / 1587 board programmed. Via Win512 / Win128 / Win512 G3 is each unit (e.g. each ext. FBP) programmed regarding Address, Selective alarm presentation, if the buzzer should be disabled etc. When required, also "User definable text messages" (alarm texts).

take place. During the download to an ext. FBP, the following will be shown in its display:

"SSD download in progress....."

8. After the download of SSD to an ext. FBP, the following will be shown in its display (very quickly):

"SSD Download Memory OK"

or

"SSD Download Memory Fault"

After that the ext. FBP will restart, see chapter "Restart", page 22.

9. The unit will then start working in normal operation mode.

9 Restart

The ext. FBP will **restart**:

- When it is powered up
- If the jumper "JP1" is activated momentarily
- After address setting (i.e. "P2" is pressed).
- If the contact with the Control unit is OK again after:

"No contact with Control unit".

During the restart will in the display be shown (no back-light):

"Checking program memory..."

and after that (very quickly)

"Program memory OK."

and after that

"SSD memory OK."

All LEDs will be turned on during the restart.

If there is a program memory fault, there will be a fault message in the display:

"Memory fault in program area (n)" (n=1 or 2).

The ext. FBP will not work.

There will also be a fault message in the c.i.e.:

In system EBL512:

"FAULT: Comm, FBP xx, 1587 board x, CU xx".

In system EBL128:

"FAULT: No reply FBP x".

In system EBL512 G3:

"FAULT: No reply, fire brigade panel xx, Control unit xx".

If there is an SSD (Site Specific Data) memory fault or no SSD downloaded, there will be a fault message in the display:

"SSD memory fault"

The ext. FBP will work since the alarm texts will be sent out from the c.i.e.

There will also be a fault message in the c.i.e.:

In system EBL512:

"FAULT: SSD, FBP xx, 1587 board x, CU xx".

In system EBL128:

"FAULT: Site specific data (SSD), FBP x.

In system EBL512 G3:

"FAULT: Site specific data, fire brigade panel xx,
Control unit xx.

10 Fault messages

The buzzer will sound continuously for any not acknowledged fault in the system or a fault in the unit. The buzzer will be silenced when all faults are acknowledged (in any c.i.e.) or with the push button "P2" (Silence buzzer).

When a fault is displayed, the display back-light is turned on and the fault messages will be displayed on the first row in the display.

A fire alarm has the highest priority, i.e. it will be displayed instead of any fault message.

NOTE! The fault presentation described above is not valid in the Swedish convention (SBF).

Here follows a list of the fault messages that might be displayed in the ext. FBP and in the c.i.e. respectively.

10.1 Fault messages in the ext. FBP

"General fault in system" ² Any not corrected / serviced fault and/or any not acknowledged fault in the EBL system. To see the fault(s), use any c.i.e. in the system.

"No contact with control unit" The contact with the c.i.e. is interrupted for ≥ 45 sec. In a brand new ext. FBP this message will be in English. After commissioning of the ext. FBP (i.e. after SSD download) the message will be in the same language as in the c.i.e. Check the cable, all connections as well as the 1582 / 1587 board in the EBL512 c.i.e. and the RS485 transceiver component 4552 in the EBL128 c.i.e. Is a correct / complete SSD download (via Win512 / Win128 Win512 G3) performed? Check the address setting on the 1582 / 1587 board in EBL512 and check the address and SW mode settings in the ext. FBP, etc.

"SSD memory fault" See chapter "Restart", page 22.

"SSD Download Memory Fault" in conjunction with SSD download, see chapter "Commissioning a new unit / SSD download", 20.

"Memory fault in program area (n)" See chapter "Restart", page 22.

10.2 Fault messages in the c.i.e.

10.2.1 System EBL512

"FAULT: 1587 board x, CU xx"

Fault on / no communication to the 1587 board No. x in control unit No. xx. Check address setting and connections on the board. Check the programming (Win512).

"FAULT: Comm, FBP xx, 1587 board x, CU xx"

The contact with the ext. FBP is interrupted. Check the cable, all connections and the 1582 / 1587 board. Is a correct / complete SSD download (via Win512) performed? Check the address setting (1582 / 1587 board / the ext. FBP), SW mode setting, etc. See also chapter "Restart", page 22.

"FAULT: FBP xx, 1587 board x, CU xx"

The ext. FBP is programmed (via Win512) as another type of unit or there is a fault in the ext. FBP.

"FAULT: Fuse, 1587 board x, CU xx"

Check for a blown fuse(s) on the 1587 board.

"FAULT: SSD, FBP xx, 1587 board x, CU xx"

See chapter "Restart", page 22.

10.2.2**System EBL128****"FAULT: No reply FBP x"**

The contact with the ext. FBP is interrupted. Check the cable and all connections. Is a correct / complete SSD download (via Win128) performed? Check the address setting, SW mode setting, etc. See also chapter "Restart", page 22.

"FAULT: FBP x"

The ext. FBP is programmed (via Win128) as another type of unit or there is a fault in the ext. FBP.

"FAULT: Site specific data (SSD), FBP x"

See chapter "Restart", page 22.

10.2.3**System EBL512 G3****"FAULT: No reply, fire brigade panel xx, Control unit xx."**

The contact with the ext. FBP is interrupted. Check the cable and all connections. Is a correct / complete SSD download (via Win512 G3) performed? Check the address setting, SW mode setting, etc. See also chapter "Restart", page 22.

"FAULT: Fire brigade panel xx"

The ext. FBP is programmed (via Win128) as another type of unit or there is a fault in the ext. FBP.

"FAULT: External presentation unit xx control unit xx"

The ext. FBP is programmed (via Win512 G3) as another type of unit or there is a fault in the ext. FBP.

"FAULT: Site specific data, fire brigade panel xx, Control unit xx."

See chapter "Restart", page 22.

11 Software (SW)

The software is stored in a flash memory in each ext. FBP. This software can be replaced / updated (i.e. downloaded via Win512 / Win128 / Win512 G3). All units connected to the same RS485 line **have to have** the same SW version and it is **highly recommended** to have the same SW version in all the display units in the system.

11.1 SW version

The SW version can be presented as follows:

- 1 Do the same as by SW mode and address setting, see chapter "SW mode setting", page 15.
- 2 When the following is displayed:

```
MODE SETTING!           Change = Black  
Type: xxxxxxxxxxxxxx   Store = Yellow
```

...press push button "P2" (yellow) and the following will be displayed:

```
ADDRESS SETTING        Change = Black  
Address: xx            Store = Yellow
```

...press push buttons "P1" (black) and "P2" (yellow) simultaneously and the following will be displayed:

```
Rst: nn Addr: aaaaaaa  Version: V.vvvv  
Return = Yellow Erase SSD = Black
```

nn = restart type (code) and **aaaaaaa** = memory address before restart.

- nn=00: Power On Reset. (Power supply connected)
- nn=01: Watchdog Reset.
- nn=02: Accidental jump to reset vector.
- nn=03: External reset caused by external watchdog / user (e.g. after SSD download) or jumper "JP1" (RESET) has been used.

nn=4-19: Unexpected interrupt.

If nn=01, 02 or 04-19 appear often, call for service personnel / engineer.

V.vvvv = SW version (e.g. 1.4.x).

- 3 Press **yellow** push button ("P2") – **or see 6 below** – and the following will be displayed:

```
ADDRESS SETTING        Change = Black  
Address: xx            Store = Yellow
```

- 4 Press **yellow** push button ("P2").


- 5 The ext. FBP will restart (**Restarting....**), i.e. the buzzer will sound for approx. two seconds and the unit will return to normal operation.
- 6 **Cont. from 3 above: Or press **black** push button ("P1") and the SSD will be erased (Erasing SSD....). The ext. FBP will restart (Restarting....), i.e. the buzzer will sound for approx. two seconds and the unit will return to normal operation.**

11.2 SW download

Each ext. FBP is equipped with an RS232 interface ("J2"), which makes it possible to connect a PC and carry out the downloading directly in the ext. FBP respectively.

1. Prepare the PC and start Win512 / Win128 / Win512 G3. In Win512 select the ext. FBP icon and click the right mouse button. Select "Download program". In Win128 and Win512 G3, in menu "Tools" select "Download FBP / EPU / AAU Software". Select the SW file to be downloaded, i.e. DU_version.BIN (where "version" is the valid program version, e.g. 14x=program version 1.4.x). Check / set the COM port and baud rate. See also the Win512 / Win128 / Win512 G3 help.
2. Connect the PC to the AAU ("J2").
3. Put the jumpers "JP3" and "JP4" in position "A".
4. Put the jumper "JP2" (BOOT) in position.
5. Put the AAU in "bootstrap" mode, i.e. put the jumper "JP1" (RESET) in position **momentarily**. The buzzer will sound.
6. Start the downloading. (The buzzer will be silenced.)
7. When the download is ready remove the jumper "JP2" (BOOT).
8. Put the jumpers "JP3" and "JP4" in position "B".
9. Do a restart, i.e. put the jumper "JP1" (RESET) in position **momentarily**. The buzzer will sound for approx. two seconds and the unit will return to normal operation.
10. Regarding fault messages, see chapter "Restart", page 22.

12 Operation

In normal operation (quiescent cond.) the LED "L6" (Operation) is turned on, the display is blank (back-light off) and the buttons are not possible to use except  (P5)¹⁶.

NOTE!

In ext FBP 1826, the door has to be opened with the key and in FBP 1828, the key has to be activated, to get access to the push buttons. If the buzzer sounds in case of a fault in the system, it can be silenced by the push button "P2" (Silence buzzer). The unit also has, a "test function", i.e. if you press push buttons "P1" (black) and "P2" (yellow) simultaneously, the buzzer will sound (cont.), all LEDs will be turned on and all dots will be shown in the display (plus back-light).

Pre-warnings, co-incident⁵, fire alarms and heavy smoke / heat alarms will be presented and printed (when a printer is available)¹⁶ like in the c.i.e. the ext. FBP is connected to (including an alarm text, if programmed).

See also chapter "Selective alarm presentation, page 8.

NOTE!

The printing in 1826 will be done only if and when the door is being opened. If the door is not opened until after all the alarms are reset, there will be no printing.

Any not corrected / serviced fault and not acknowledged fault in the system will be presented as "General fault in system".²

The buzzer sounds for any not acknowledged fault in the system.²

Fire alarm reset can be done in any ext. FBP and in any c.i.e.²⁷

When all fire alarms are reset, all ext. FBPs will return to normal operation (quiescent cond.).

The following page / figure show an operation summary for the ext. FBP 1826 (and 1828).

See also chapter "SW mode & Address setting, page 15.

NOTE!

The ext. FBP in the figure is only schematic, i.e. the positions of the different LEDs, push buttons, etc. are not according to Figure 3, on page 10.

²⁷ **Single reset / Multiple reset / Single encapsulated reset** (like in the c.i.e.): Press "P4". Independent of the c.i.e., the following is valid in 1826/28 – 1587 mode:

Multiple reset: Press "P4" and "P5" simultaneously.

Single encapsulated reset: Press "P4" and "P1" simultaneously.

For more information regarding the reset alternatives, see the Operating instructions for the system respectively.

Ext. FBP 1826 & 1828




Figure 5. Operation summary for the Ext. FBP 1826 (and 1828). (Co-occurrence alarm = 2-zone / address dependence.). Any fault in the system will be presented as "General fault in system" and the buzzer will sound continuously for any not acknowledged fault in the system.² "Silence buzzer" is possible to use.

NOTE! When 1826 has a printer mounted, there will be a test print-out in conjunction with the test function.

13 Connections

The ext. FBP 1826 / 1828 main board is equipped with a plug-in terminal block (J1:1-8) for the cable connections. Up to 1.5 mm² conductor area can be used.




Figure 6. The connections to the ext. FBPs 1828 & 1826 terminal block "J1". The jumper "JP8" only has to be on place (shunted) in the last unit on the line.
NOTE!
 In EBL128: +24 V / 0V / S0 / S1 to terminal block J1: 13 / 14 / 15 / 16.
 In EBL512 G3: +24 V / 0V / S0 / S1 to terminal block J4: 35 / 36 / 37 / 38.




Figure 7. The ext. FBPs 1826 & 1828 main board p.c.b. Position of the terminal block "J1", the jumper "JP8", etc.

Comments to the components:

F3	1.5 A fuse (not replaceable; the whole p.c.b. should be replaced).
J1	Terminal block for the ext. FBP's connections.
J2	"D" connector (9 ways, male), RS232 interface for SW download. (Note, jumpers "JP3" and "JP4" have to be in pos. "A".)
J3	Connector for door contact (1826) / key switch (1828).
J4	Used when SW mode and address setting shall be done.
J8	Not used in 1826 & 1828.
J10	Connector for printer (1835) board in 1826.
J11	Connector for printer (1835) board in 1826.
JP1	Reset. (Restart of the ext. FBP.)
JP2	Boot. (The ext. FBP has to be in "bootstrap" mode before SW download.)
JP3	Pos. "A": PC, for SW download, connected via "J2". Pos. "B": The ext. FBP is connected to the c.i.e. (default).
JP4	Pos. "A": PC, for SW download, connected via "J2". Pos. "B": The ext. FBP is connected to the c.i.e. (default).
JP8	Used when the ext. FBP is the last unit on the line, i.e. to connect the built-in end-of- line resistor (120R).
JP9	Paper feed. (Normally not used.)
KEY1LED1	Connector for the front panel.
P1	Potentiometer for LCD contrast.

14 **Technical data**

14.1 **Power supply**

Nominal voltage for the ext. FBPs 1826 & 1828 is 24 V DC.²⁸

The number of ext. FBPs²⁹ that can be power supplied from the c.i.e. is depending on if each ext. FBP 1826 has a printer or not, as well as all other units connected to the same RS485 line (i.e. the current consumption).

As an alternative, the units can be power supplied from an external power supply.

14.2 **RS485**

The ext. FBPs communicate with the c.i.e. via RS485, i.e. in system EBL512 via an "Ext. FBP / DU interface board" 1587 (data rate 9600 baud) or an "Ext. FBP interface board" 1582 (1200 baud), mounted in the c.i.e. and in system EBL128 via an "RS485 transceiver component 4552" plugged on the mother board in the c.i.e.

In system EBL512 G3 the required components are mounted on the main board by delivery.

In the last unit on the RS485 line, a termination resistor (120R) has to be connected. In the ext. FBPs 1826 & 1828 this is done via jumper "JP8". ("JP8" mounted = the termination resistor is connected.)

14.2.1 **Cable**

The cable to be used in systems EBL512 and EBL512 G3 is LiYCY (Twisted Pairs) 2 x 2 x 0.75 mm² (screened - tinned copper braid) or equivalent. Cable length up to 1200 m (theoretically) but the cable length is also depending on the current consumption, i.e. the type and number of units connected on the RS485 line.

NOTE! In system EBL128 the screen is not used / connected. 2 x ELQYB 2 x 1 mm (0.75 mm²) can then be used.

14.3 **RS232**

The ext. FBPs are equipped with an RS232 interface (J2), which makes it possible to download new SW directly to the ext. FBP respectively.

14.4 **Connection**

The ext. FBPs are equipped with a plug-in terminal block (J1) for the cable connections. Up to 1.5 mm² conductor area can be used.

²⁸ Allowed voltage is 12 – 30 V DC.

²⁹ On each 1582 board are up to eight addresses for Display Units available. On each 1587 board are up to sixteen addresses available.

14.5 **Current consumption**

The current consumption is depending on the type of units and the actual voltage on the line.

The following table shows the current consumption for the different units in relation to the actual line voltage (min. and normal respectively):

Unit	Current consumption			
	Quiescent (mA)		Active (mA)	
	12 V DC	24 V DC	12 V DC	24 V DC
Ext. FBP 1826 / 1828	48	26	88	49
Printer 1835 ³⁰	7	4	345	161

³⁰ Printer 1835 can only be mounted in ext. FBP 1826.

15 **Revision history**

Revisions are, when possible, written with red font colour.

Revision 1

- 1 Info. revised and/or added.
- 3.1.1 Info. revised and/or added.
- 3.1.2 Info. revised and/or added.
- 3.2.1 Info. revised and/or added.
- 3.2.2 Info. revised and/or added.
- 6 Info. revised.
- 6.1 Info. revised and/or added.
- 6.2 Info. revised.
- 7 Info. revised.

Revision 2

- 3.2.1 Info bold.
- 5.1 "L1" & "L2", info added. "P3", footnote 11 added.
- 11.1 Display text revised. Info added.

This page has deliberately been left blank.

Panasonic ideas for life

Panasonic Electric Works Nordic AB

Jungmansgatan 12, SE-211 19 Malmö, Sweden

Tel: +46 (0)40 697 70 00 • Fax: +46 (0)40 697 70 99

info-fste@eu.pewg.panasonic.com • www.panasonic-fire-security.com

