


Panasonic


Uniguard UG-4-PEW Installation instructions 3312, 3312F/FL (4301)

Panasonic Electric Works Nordic AB



Jungmansgatan 12
SE-211 19 Malmö, Sweden
Tel: +46 (0)40 697 70 00
Fax: +46 (0)40 697 70 99
www.panasonic-fire-security.com





1




2





3




4




5




6



7



8




Panasonic


Uniguard UG-4-PEW Installation instructions 2324 (4352)

Panasonic Electric Works Nordic AB



Jungmansgatan 12
SE-211 19 Malmö, Sweden
Tel: +46 (0)40 697 70 00
Fax: +46 (0)40 697 70 99
www.panasonic-fire-security.com





1




2





3




4




5



6



7



8

